



EXPERT-7 is the premier quality diazo emulsion for use in the making of photo-stencils for screen printing. And it has excellent development. In this way the film is very softer and printing is very well.

EXPERT-7 consists of the following Three materials.(1kg, 5 kg set) EMULSION 0.9kg 4.5kg SENSITIZER 100 cc POLY BOTTLE 250cc POLY BOTTLE DYE 10 cc POLY BOTTLE 30ccPOLY BOTTLE Additional water 0.1kg 0.5kg(for dissolving sensitizer) TOTAL 1kg 5 kg

Use of EXPERT-7 Handle EXPERT-7 under subdued light conditions.

Dissolve the sensitizer with 0.1kg water. Pour sensitizer solution into emulsion and mix it thoroughly. Mix dye and emulsion if you need colored emulsion.

Pre-Cleaning of screen In order to get good adhesion between emulsions and screen, use a screen cleaner "SCREEN CLEANER EMC-58".

Coating

Coat the sensitized emulsion onto screen (outer-side which touches directly object materials). 1.Stand screen vertically. 2.Coat once from bottom to top. 3.Turn up side of screen down. 4.Coat from bottom to top(opposite direction).

Drving

Dry coated screen in temperature not higher than 40°C for 15~20min. After drying, the screen should be kept in a cool and dark room.

*Repeat these coating and drying operation until the emulsion becomes the thickness you need.

Exposure

Before production use, determine the correct exposure time for your work by some experiments.

Reference data

EMULSION	SCREEN		THICKNESS	EXPOSURE TIME
EXRERT-7	Polyester 225mesh Yellow	4kw High pressure mercury lamp	10µm	60sec
		3kw Metal halide lamp		120sec

*Using Light source at 1 meter distance

Development

Immerse the exposed screen in water for a few minutes, wash it out with a low-pressure spray of water, and then dry it.

*Re-exposure after developing and drying makes screen emulsion stronger.





HEAD OFFICE / 648 Yakushi-cho Nijyo-agaru Nishinotoin Nakagyo-ku,Kyoto,JAPAN TEL0081-75-211-4416 FAX0081-75-211-4497 TOKYO OFFICE / 6-2-14 Honkomagome Bunkyo-ku, Tokyo, JAPAN OSAKA OFFICE / 3-3-10 Shinmachi Nishi-ku, Osaka, JAPAN UJI FACTORY / 58 Nakagawara Makishimacho Uji, Kyoto, JAPAN

SPEC We will revise & improve without informing





TEL0081-3-3947-0505 FAX0081-3-3947-0952 TEL0081-6-6532-3855 FAX0081-6-6533-0030 TEL0081-774-23-5333 FAX0081-774-24-1916